

## Pre-Arrival Notification / Security Report

Description	Receiving data regarding <b>Pre-Arrival Notification</b> (corresponding to <b>IMO Security Report</b> ) for the given vessel and port call.			
Request Details				
IMO Data Number	Name	Description	Format	Sample
	Vessel Arrival Drafts	Drafts of both the forward and aft of the ship when it arrives in the port	an..4,2	
	Ship email address	Email of the ship	an..50	
	Ship arriving from	Direction that the ship is arriving from	an..1	N – North S – South E – East W – West
IMO0379	Air Draft	The height from the waterline to the highest point of the ship.	an..4,2	
	INMARSAT number	INMARSAT number of the ship	an..12	870xxxxxxxxx
	Ship owner company name	Name of ship owner company	an..4,2	
IMO0001	Agent City	City of the referenced agent at port	an..35	
IMO0002	Agent contact name	Name of agent in Singapore	an..70	
IMO0003	Agent Country Code	A code representing the country address of the referenced agent at port	a2	
IMO0006	Agent email	The email address for the referenced agent at port.	an..50	
IMO0008	Agent landline number	The landline telephone number for the referenced agent at port.	an..50	
IMO0009	Agent mobile number	Mobile number of the referenced agent at port.	an..50	
IMO0010	Agent Name	The name of the agent at the port of arrival.	an..70	
IMO0014	Authentication Date	The date of authentication	an..35	
IMO0015	Authenticator Location	The location of the person when submitting the security related information.	an..17	

IMO0016	Authenticator Name	The name of the person attesting to the validity of the transmitted information.	an..70	
IMO0018	Authenticator party identification number	An identifying number, such as an agent identifier, of the party attesting to the validity of the transmitted information.	an..17	
IMO0019	Cargo brief description	A description of the type of cargo carried on the ship in general terms	an..256	
IMO0031	IMO company number	The unique company identification number shown in the Continuous Synopsis Record (CSR).	an..17	
IMO0032	Ship company name	The name of the company	an..70	
IMO0033	Company security officer email	The contact email address for the company security officer shown in the ship security plan.	an..50	
IMO0034	Company security officer landline number	The contact landline number for the company security officer shown in the ship security plan.	an..50	
IMO0035	Company security officer mobile number	The contact mobile number for the company security officer shown in the ship security plan.	an..50	
IMO0036	Company security officer name	The name of the company security officer shown in the ship security plan.	an..70	
IMO0046	Dangerous goods carried indicator	Indicate whether the ship is carrying dangerous goods	an..1	Y – Yes N – No
IMO0064	Estimated Time of Arrival (ETA)	ETA to port	an..35	
IMO0065	Estimated time of Departure (ETD)	ETD from port	an..35	
IMO0067	Valid Certificate Indicator	A "yes/no" indicator whether the ship has a valid certificate of the indicated type.	an..1	Y – Yes N – No  (MPA – CLC, BCC and ISSC required)
IMO00308	Certificate type acronym	Acronym of the certificate  Required if any of the certificate indicators are “Y”	an..10	MPA – CLC, BCC and ISSC required)

		1 entry required per "Y"		
IMO0071	Certificate Expiry Date	Expiry date of the certificate  Required if any of the certificate indicators are "Y"  1 entry required per "Y"	an..35	
IMO0070	Certificate issuer flag State, coded	The code representing the country of the flag that issued the certificate.	a2	
IMO0129	Certificate issuer name	Name of the body/organization that issued the certificate (in case it is a notified body, an insurance company or other).	an..70	
IMO0108	Port of arrival, coded	A code representing the port where the ship arrives.	an5	
IMO0109	Port of arrival name	A name and country of the port where the ship arrives.	an..256	
IMO0110	Port of call sequence number	A number indicating the order of a port of call on a list.	n..5	
IMO0184	Port facility, coded	A code representing the port facility at the port of call.	an..17	
IMO0185	Port Facility Name	Name of port facility (port facility that the ship will be going to on arrival)	an..256	
IMO0188	Previous port facility name	The name and country of a previous port facility called at during a previous port call.	an..256	
IMO0189	Previous port facility, coded	A code representing a previous port facility called at during a previous port call.	an..17	
IMO0124	Previous port facility call start date	The start date of a previous port facility call.	an..35	
IMO0125	Previous port facility call end date	The end date of a previous port facility call.	an..35	
IMO0126	Previous port of call name	The name and country of a previous port of call.	an..256	
IMO0127	Previous port of call, coded	A code representing a previous port of call.	an5	
IMO0149	Ship security level in a previous port, coded	A code representing the security level of the ship in a previous port as defined by the ISPS Code.	an..3	SL1 – Security level 1 SL2 – Security level 2

				SL3 – Security level 3
IMO0128	Authenticator role, coded	A code providing the role of the person attesting to the validity of the transmitted information.	an..3	
IMO0130	Security Plan approval indicator	A "yes/no" indicator of whether the ship is provided with an approved security plan on board.	n1	
IMO0131	Security, other matters to report	An explanation of any other security-related matters to report.	an..512	
IMO0133	Ship additional security measures, coded	A code representing a description of special or additional security measures applied in lieu of those in the security plan.	an..3	
IMO0135	Ship additional security measures, description	The description of special or additional security measures applied in lieu of those in the security plan.	an..512	
IMO0137	Ship current security level, coded	A code representing the security level of the ship in the port of arrival as defined by the ISPS Code.	an..3	SL1 – Security level 1 SL2 – Security level 2 SL3 – Security level 3
IMO0136	Ship call sign	A unique ship's identification used primarily for radio communications.	an..7	
IMO0138	Ship flag State, coded	A code representing the nationality of the ship shown on its IMO ship's certificate.	a2	
IMO0139	Ship gross tonnage	The gross tonnage shown on the ship's International Tonnage Certificate or other document issued by the flag State or recognized organization.	n..14,3	
IMO0140	Ship IMO number	The unique ship identification number shown on its IMO ship's certificate.	an..7	
IMO0141	Ship satellite service, number	The unique recognized mobile satellite service call number assigned to the ship by the operator and recorded in the operator's ship directory where provided.	n..14	

IMO0142	Ship name	The ship's name shown on the IMO ship's certificates.	an..70	
IMO0147	Ship registry port, coded	A code representing the port of registry shown on the IMO ship certificate.	an5	
IMO0148	Ship registry port name	The name and country for the Port of Registry shown on the IMO ship certificate.	an..256	
IMO0161	Ship-to-ship activity, coded	A code representing the ship-to-ship activity which has been carried out during the period of the last ten calls.	an..3	
IMO0162	Ship-to-ship activity	A description of the ship-to-ship activity which has been carried out during the period of the last ten calls.	an..512	
IMO0163	Ship-to-ship activity end date	The end date of the ship-to-ship activity which has been carried out during the period of the last ten calls.	an..35	
IMO0165	Ship-to-ship activity sequence number	A number showing the order of ship-to-ship activity which has been carried out during the period of the last ten calls.	n..5	
IMO0164	Ship-to-ship activity location name	The name and country to describe where the ship-to-ship activity has been carried out during the period of the last ten calls.	an..256	
IMO0166	Ship-to-ship activity start date	The start date of the ship-to-ship activity which has been carried out during the period of the last ten calls.	an..35	
IMO0167	Ship-to-ship activity location, coded	A code representing the location of the ship-to-ship activity which has been carried out during the period of the last ten calls.	an5	
IMO0194	Ship-to-ship activity location, latitude	The latitude (geographical coordinate) of the location of the ship-to-ship activity which has been carried out during the period of the last ten calls.	an..10	
IMO0195	Ship-to-ship activity location, longitude	The longitude (geographical coordinate) of the location of the ship-to-ship activity which has been carried out during the period of the last ten calls.	an..11	

IMO0172	Primary purpose of call, coded	A code representing the primary reason for the ship to enter the referenced port.	an..1	1 – Cargo Operation  2 – Embarking/dise mbarking Passenger  3 – Taking Bunkers  4 – Taking Supplies  5 – Changing Crew  6 – Repair/Docking/ Outfitting  7 – Offshore
	Contracted security personnel indicator	To indicate presence of privately contracted security personnel onboard ship	an..1	Y – Yes N – No
	Refugees/stowaways/rescues from sea indicator	To indicate presence of refugees/stowaways/rescues from the sea onboard ship	an..1	Y – Yes N – No
	Arms and ammunition indicator	To indicate the presence of arms or ammunitions onboard for the vessel's personal use (exclude cargo)	an..1	Y – Yes N – No
	Type and quantity	The type and quantity of arms and ammunitions on board (excluding cargo)  Required if Indicator of arms and ammunition is "Y"	an..80	
	Unmanned aircraft in port indicator	Indicate if the vessel will be operating any unmanned aircraft (e.g. radio-controlled aircraft, drones, remote-controlled kites, etc.) while in port.	an..1	Y – Yes N – No
	Location of report	Location of the ship at the time the report is made, in terms of Latitude (degrees N/S),	an..256	3°0'0"N 101°24'0"E Port Klang

		Longitude (degrees E/W) and port name if applicable		
	Datetime of report	Datetime the report was made	an..35	
	Declared by	Name of declarant	an..70	

## General Declaration / FAL 1

Description	Receiving data regarding <b>General Declaration</b> (corresponding to IMO Compendium <b>FAL Form 1</b> ) for the given vessel and port call.			
Request Details				
IMO Data Number	Name	Description	Format	Sample
IMO0013	Arrival/departure code	A code in the message to show whether the information is submitted for the ship arrival or departure.	a1	e.g. A – Arrival D – Departure C – Combined
IMO0063	Date and time of arrival - actual	The date and time the ship arrives at a specified location, ATA.	an..35	
IMO0064	Date and time of arrival - estimated	The date and time the ship is estimated to arrive at a specified location, ETA.	an..35	
IMO0065	Date and time of departure - actual	The date and time the ship departs from a specified location, ATD.	an..35	
IMO0066	Date and time of departure - estimated	The date and time the ship is estimated to depart from a specified location, ETD.	an..35	
IMO0075	Last port of call name	The name and country of the port immediately previous to the port of arrival.	an..256	
IMO0076	Last port of call, coded	A code representing the port immediately previous to the port of arrival.	an5	
IMO0083	Name of master	The name of the person in charge of the ship.	an..70	
IMO0084	Next port of call, coded	The port immediately subsequent to the port of departure.	an5	
IMO0085	Next port of call name	The name and country of the port immediately subsequent to the port of departure.	an..256	
IMO0086	Number of crew	The count of persons actually employed for duties on board during a voyage in the working or service of a ship and included in the crew list.	n..4	
IMO0087	Number of passengers	The count of persons on board the ship who are passengers as defined by SOLAS.  Mandatory if purpose code is 2.	n..4	



IMO0108	Port of arrival, coded	A code representing the port where the ship arrives.	an5	
IMO0109	Port of arrival name	A name and country of the port where the ship arrives.	an..256	
IMO0111	Port of departure, coded	The code representing the port from which the ship departs.	an5	
IMO0112	Port of departure name	A name and country of the port from which the ship departs.	an..256	
IMO0014	Authentication date	The date of authentication.	an..35	
IMO0016	Authenticator name	The name of the person attesting to the validity of the transmitted information.	an..70	
IMO0017	Authenticator party identification number	An identifying number, such as an agent identifier, of the party attesting to the validity of the transmitted information.	an..17	
IMO0019	Cargo brief description	A description of the type of cargo carried on the ship in general terms.	an..256	
IMO0142	Ship name	The ship's name shown on the IMO ship's certificate.	an..70	
IMO0140	Ship IMO number	Ship unique identifier.	n..7	
IMO0160	Ship type, coded	The type of the ship shown on its IMO ship's certificate.	an..4	
IMO0139	Ship gross tonnage	The gross tonnage shown on the ship's International Tonnage Certificate or other document issued by the Flag State or Recognized Organization.	an..14,3	
	GT Change Indicator	Indication that there is a change to the Gross Tonnage of the ship from the last submission	an..3	Y – Yes N – No
	Effective Date	Date that the new Gross Tonnage is effective. Required if GT Change Indicator = "Y"	an..35	
IMO0143	Ship net tonnage	The net tonnage shown on the ship's International Tonnage Certificate or other document issued by the Flag State or Recognized Organization.	an..14,3	
IMO0376	Deadweight Tonnage (DWT)	The difference in tonnes between the displacement of a	an..16,6	

		ship in water of a specific gravity of 1.025 at the actual draught and the lightweight of the ship.  When Vessel Type is TANKER or PARCEL TANKER, the value cannot be zero or blank.		
IMO0147	Ship registry port coded	A code representing the port of registry shown on the IMO ship certificate.	an..5	UNLOCODE
IMO0148	Ship registry port name	The name and country for the Port of Registry shown on the IMO ship certificate.	an..256	
IMO0136	Ship call sign	A unique ship's identification used primarily for radio communications.	an..7	
IMO0138	Ship flag State, coded	A code representing the nationality of the ship shown on its IMO ship's certificate.	a2	
	Owner name	Name of the ship owner	an..256	
	Owner name change indicator	Indicate if there has been a change in owner name.	an..3	Y – Yes N – No
	Country of owner	Country of Owner	an..256	
	Country of owner change indicator	Indicate if there has been a change in the country of owner	an..3	Y – Yes N – No
IMO0064	ETA	The date and time the ship is estimated to arrive at the port of arrival.	an..35	
	Total Cargo on Board	Total volume of cargo on board, measured in Freight Tonnes.  Required only if purpose of call code is 1 (Cargo Operation)		
IMO0083	Master name	The name of the person in charge of the ship.	an..70	
IMO0172	Primary purpose of call, coded	A code representing the primary reason for the ship to enter the referenced port.	an..1	1 – Cargo Operation  2 – Embarking/disembarking Passenger  3 – Taking Bunkers  4 – Taking Supplies

				5 – Changing Crew  6 – Repair/Docking/Outfitting  7 - Offshore
IMO0191	Voyage number	An operator-assigned reference code for the ship's voyage.	an..17	
IMO0196	Remarks	Statement of any other information relevant to ship arrival, stay or departure.	an..512	
IMO0306	Certificate identifier	The identifier of the certificate, defined by the issuing organization.	an..35	
IMO0145	Certificate issue date	The date the certificate was issued.	an..35	
	Grade of Bunkers	Grade of Bunkers taken  Required if Purpose code is 3 (Taking Bunkers)	an..3	MDO MFO MGO
	Bunker Quantity Taken	Quantity of bunker taken, measured in tonnes.  Required if Purpose code is 3 (Taking Bunkers)	a..3	
	CST (CentiStoke)	Mandatory if Grade of Bunker contains MFO		
	Charter's Nationality	Nationality of charterer		Valid Indicator is 1, 2 or 3
	Shipyard Location Reference	Reference to the values for the shipyard locations.  Required if Purpose code is 6		
	Shipping Line, Coded	Must be valid value from the PT-Parameters code list of shipping lines	an..3	